

# EVOC Cone Trailers



## When using the cones trailers:

- **Unload cones from back to front. This will prevent the tongue of the trailer rising.**
- Do not exceed 15 MPH.
- Do not stack more than 25 cones per paillon.
- Stack the cones in accordance with the size of the base plate on the paillon.
- Do not remove the cone trailer, or any of the cones from the EVOC facility without written approval of the Douglas County Sheriff's Office or the HRLETF.
- Use provided wheel chocks when trailer is not hitched to a vehicle.
- To tow the trailer, you must use a hitch with a 2" ball.
- Hitches and tow vehicle(s) are not provided.
- Cones and trailers must be returned to their proper location upon completion of the class.
- Any damage or problems shall be reported to the EVOC facility director.

## Cone Trailer Locations:

- Cone trailer #1 is designated for the outside Perimeter Road Course, and is stored at the lot to the south of Skills Pad "A."
- Cone trailer #2 is designated for Skills Pad "A," and stored at, the lot to the south of Skills Pad "A."
- Cone trailer #3 is designated for, and stored at, Skills Pad "B."
- Each cone trailer holds 500 cones of various sizes.